EPSON PRODUCT SUPPORT BULLETIN

Date: 11/8/04 Originator: RB, CH, JD, SA

PSB #: PSB.2004.03.001C Authorization:
Reference: PSB.2004.03.001A Total Pages: 19

Product(s): EPSON Stylus Color 3000, Stylus Pro 4000, 5000, 5500, 7000 Series, 7600 Series, 9000 Series, 9600 Series,

10000 Series, and 10600 Series

Subject: Maximum Printable Area Limits for the EPSON Professional Graphic Printer line.

This bulletin was created to inform you of the maximum custom page sizes allowable for EPSON Professional Graphic products. The tables below show the maximum page sizes allowable for the EPSON Professional Graphics printer line (Desktop and Large Format). Although this document is meant as a guideline for the maximum page size allowable for each printer, it does not include printable area (margin) information. Please refer to your user guide for additional information regarding the printable area (margins) for your particular printer. There are 3 aspects that effect how long of a page your printer can output. Those 3 items are:

- 1. Operating System.
- 2. Driver Specification.
- 3. Software application(s) being used.

Maximum custom page size allowable per operating system (for Epson standard driver):

	Stylus Color 3000	Stylus Pro 4000	Stylus Pro 5000	Stylus Pro 5500	Stylus Pro 7000	Stylus Pro 7500	Stylus Pro 7600	Stylus Pro 9000	Stylus Pro 9500	Stylus Pro 9600	Stylus Pro 10000 Series
Macintosh OS	44 in.	44 in.	44 in.	44 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.
Macintosh OS X*	44 in.	44 in.	N/A	44 in.	N/A	N/A	90.5 in.	N/A	N/A	90.5 in.	90.5 in.
Win 9x/Me	44 in.	44 in.	44 in.	44 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.
Win NT 4.0/2000/XP	44 in.	44 in.	44 in.	44 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.

Print jobs being sent through the Epson standard print driver should be in the RGB format in order for color management to be utilized properly.

^{*} Macintosh OS X allows you to create any paper size regardless of printer driver's limitations. Exceeding these limitations will result in your image being cropped and printed at 8.5 x 11.

Maximum custom page size allowable for EPSON PostScript options (PPD):

	Stylus Color 3000	Stylus Pro 4000	Stylus Pro 5000	Stylus Pro 5500	Stylus Pro 7000	Stylus Pro 7500	Stylus Pro 7600	Stylus Pro 9000	Stylus Pro 9500	Stylus Pro 9600	Stylus Pro 10000 Series
EPSON Stylus RIP	44 in.	N/A	44 in.	N/A							
EPSON Fiery RIP Station	N/A	N/A	44 in.	N/A	See NOTE 1	See NOTE 1	N/A	See NOTE 1	See NOTE 1	N/A	N/A
EPSON Fiery Spark Designer (Mac)	N/A	N/A	N/A	44 in.	N/A						
EPSON Fiery Spark Professional	N/A	N/A	N/A	44 in.	N/A	N/A	See NOTE1	N/A	N/A	See NOTE1	See NOTE 1
EPSON ColorBurst RIP	N/A	See NOTE1	N/A	44 in.	N/A	N/A	See NOTE1	N/A	N/A	See NOTE1	See NOTE 1

Print jobs being sent through the Epson PostScript driver can be either RGB or CMYK format. Settings in the RIP will determine how color management is used.

Maximum page size allowable from software applications:

	Stylus Color 3000	Stylus Pro 4000	Stylus Pro 5000	Stylus Pro 5500	Stylus Pro 7000	Stylus Pro 7500	Stylus Pro 7600	Stylus Pro 9000	Stylus Pro 9500	Stylus Pro 9600	Stylus Pro 10000
	00.0.000	1 10 1000	1.0000	1 10 0000	1107000	1101000	1101000	1.0000	. 10 0000	1.00000	Series
Adobe Photoshop 5.x/6.x/7.x/	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2
Adobe Photoshop CS	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2	See NOTE 2
*Adobe Illustrator 8.x/9.x	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.
*Adobe Illustrator CS	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.
QuarkXPress 4.x/5.x/6	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.
*CoreIDRAW 8.x/9.x/10.x/11.x	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.

2

* These applications allow for tiling of print pages, therefore allowing you to print beyond the printers maximum page length limit and print to the applications limits. The printer driver must be set for Roll Paper (Banner) mode so that page breaks at the printer's maximum page length do not occur (in essence gives you a 0 margin for the bottom of the page). The Stylus Pro 5000/5500 however will give a slight page break at the 44 inch limit as these printers do not support banner mode. Also, printing certain elements from these applications may not utilize color management correctly/properly and may produce output color that is not expected.

NOTE 1:

- a. Under Win 9x/Me, the PPD limit is 129 inches.
- b. Under Windows NT, 2000 and XP, the PPD limit is 1771.6 inches (SP7000/9000 Series) and 1800 inches (SP7600/9600/10000 Series).
- c. Under Mac OSX/8.x/9.x, the PPD limit is 273.06 inches.

NOTE 2:

Adobe Photoshop has a pixel limitation of 30,000 pixels, which means that a document created @ 300ppi can only reach a maximum page size of 100 inches (H and V). When sending jobs to the printer via the standard non-PostScript print driver, Photoshop looks at the input resolution of the printer driver and adjusts the page size accordingly. All Epson large format printers use 360dpi as the input resolution (this is the resolution data is rasterized at), therefore when printing from Photoshop, the maximum page length you will be able to output to any Epson large format printer using the standard Epson print driver would be 83.33 inches (30,000 pixels / 360dpi). As for the Epson desktop products, they rasterize data at 720dpi, therefore the maximum page length obtainable with the standard print driver would be 41.67 inches (30,000 pixels / 720dpi).

Also, under Photoshop 5.x/6.x for the Macintosh and Photoshop 6.x for the PC, the job will end up clipped if it is over the 83.3inch printer page limit. In Photoshop CS, the print job will end up clipped if it is over the 86inch printer page limit; however it will allow you to create a custom paper size of 91inches max. If you are using Photoshop 5.x for the PC, the print job will actually be truncated to fit within the printable area of the printer. Be advised that you may not get a page size error. It may be useful to enable the "print preview" function of your printer driver (if available) so that you do not waste unnecessary media.

The only options for printing beyond the limitations is to save the file and print via an application that does not have the 30,000 pixel limit (may lose color management functions) or print the file through a PostScript RIP (which will allow for longer pages).

UPDATE: Photoshop CS allows for a maximum Pixel limit of 300,000 x 300,000 (this would create a 251.5 GB file!!) This allows Photoshop to have a print dimension of 4166.666 x 4166.666 at 72 ppi (Pixels per Inch). At 360 ppi, your max print size would be 833.333 x 833.333. You can still only print 44 x 90.5" Photoshop CS at this point exceeds the capability of our printers.

For Windows Users, if you encounter partial/incomeplete prints while having Finest Detail enabled, please disable this setting. It is recommended for low resolution text and line art to sharpen their edges. For photos, this may create a massive print file that is too large for the printer driver to process correctly.

The following examples show how to setup banner printing from Adobe Illustrator 8.x/9.x and CorelDRAW 9 from the PC platform. The Macintosh versions of these applications should be very similar in function. Please refer to your software documentation for additional assistance.


Adobe Illustrator CS:

In this example, we are creating a banner, which is 227 inches (Illustrators max. page setup).

NOTE:


Mac O/S 10.3.3 system is used in this example. Windows versions of this application should be very similar in functionality. Please refer to your software documentation for additional assistance. In this example, a "20 inches wide X 180 inches high" document is created.

1. Click on File and New, set up the width and height (sample shows 20 W x 180 H), then click OK.




2. Insert the image you want to print and stretch it until it covers the whole page.

- 3. Click on File, Print, click Setup, under Tiling click on the drop down arrow, select Tile Full
- 4. Pages and click the Printer button.



- When the printer setup window comes up, select your printer name and set the Roll Paper Options to: Roll Paper Banner
 Roll Paper Banner – No Margin (if printing no margins)
- 6. In the Copies and Pages section, click on the drop down arrow, select Roll Paper Option. Uncheck Auto Cut then check Save Roll Paper.

7. Then click on **Print.** This will bring you back to the **Print** window.



8. This time click on **Page Setup**, you see the following screen, just click on **Continue** (If you don't want to see the window again, place a check mark on **Don't Show Again** box).




9. When Page Setup is open, click on the down arrow for Custom Paper Size.


NOTE:

When creating the custom page size, divide the banner size by a value that will make it less than the printer maximum custom page size (90.5 inches). In this example we take (180/2 = 90), therefore the custom page size created would be 20x90 (inches).

10. Click on **New**, name the custom size (i.e. 20 x 180 in this example), under **Paper Size** type in 20 inches for the width and 90 inches for the height, margins should be set to zero (0). Click on **Save**. Click on the down arrow again in the **Custom Paper Size** and select **Page Attributes**.




11. Under **Paper Size**, click on the drop down arrow and select the custom paper size you created (i.e. 20 X 180) orientation is set to portrait mode. Then click **OK**.



12. In the **Print** windows the preview pane will show 2 grids or pages. This indicates that a full image is tiled.

13. Click on **General**, then click the square on **Reverse Order**.




4. Click on Print.

- **NOTE 1:** When enabled, the first page will be printed first, instead of the last page first. Or Change the orientation to "Reverse", then you don't have to check the "Reverse Order".
- **NOTE 2:** Always select the custom page size last, if not, it will default to other paper sizes.
- **NOTE 3:** Before printing a large document, make sure you have enough ink to prevent getting an Ink Out message, causing the print job to stop and not completing the entire print.

Adobe Illustrator 8.x/9.x:


In this example, we are creating a banner, which is 227 inches (Illustrators max. page setup).


- 1. Launch Illustrator and open or place your file in the page layout.
- 2. Click on **File**, then **Document Setup**. The following screen appears.
- 3. Uncheck **Use Print Setup**, enable **Tile Full Pages** and create the page size (in our example we used 44x227 inches).



4. Click, **Print Setup**. This will bring up the print driver.


5. Click on the **Paper Tab**. The following appears.





- 6. Set the Paper Source to Roll Paper (Banner) and also enable Save Roll Paper.
- 7. When creating the custom page size, divide the banner size by a value that will make it less than the printer maximum custom page size. In this example we take (227/3 = 75.7), therefore the custom page size created would be 44x75.7 inches. The reason for this is to save media.


8. After setting the custom page size and other driver settings (media type, resolution, etc.), click **OK**. This will bring you back to the document setup. Now double-click the "Page" tool.



CoreIDRAW:


In this example, a banner is created at 227 inches.

- 1. Launch CorelDRAW and open or place an image in your page layout.
- 2. Adjust the page size and image for the document as shown in the following image.




3. Click on File and Print Setup.

4. Click on the Paper Tab. The following appears.




5. Set the Paper Source to Roll Paper (Banner) and also enable Save Roll Paper.

6. When creating the custom page size, divide the banner size by a value that will make it less than the printer maximum custom page size. In this example we take (227/3 = 75.7), therefore the custom page size created would be 44x75.7 inches. The reason for this is to save media.




7. After setting the custom page size and other driver settings (media type, resolution, etc.), click **OK**. This will bring you back to the document.

8. At this point, click File then Print. CorelDRAW will then run a pre-flight check and will show the following window.



9. Click on the Layout Tab and enable Print Tiled Pages and set any additional parameters as you see fit.



10. At this point you could check other tab settings (if necessary) and click **Print Preview** (recommended) if you want to see how the file will be printed or **Print** to output the file to your printer.

For all other applications, please refer to your software documentation for information on maximum custom page sizes for documents, banners or tiling prints.

EPSON PRODUCT SUPPORT BULLETIN

Date: 05/24/03 Originator: rws

Bulletin #: PSB.2003.05.001 Authorization:

Reference: NA Total Pages: 12

Product: Stylus Pro 7600/9600

Subject: MAC OS X Driver Installation and Removal

INTRODUCTION:

This bulletin was created to inform you how to Install and or Remove the Epson Stylus Pro 7600 and Stylus Pro 9600 inkjet printer driver on a Macintosh OS X system.

If this is a fist time Epson Stylus Pro 7600 or Stylus Pro 9600 inkjet OS X printer driver installation you will only need to follow the driver installation steps.

If you have previously installed the Epson Stylus Pro 7600 or Stylus Pro 9600 inkjet printer driver on your computer you must first Remove the driver from your system prior to performing the driver installation, this insures a complete driver installation.



The Epson Stylus Pro 7600 or Stylus Pro 9600 inkjet printer driver installation requires **Macintosh OS X 10.2.5** minimum.


INSTALLING THE DRIVER

- 1. After the driver is downloaded to your desktop a new folder is created (example: epson10673). Please read the files in this folder as they provide additional information for installing or using the driver.
- 2. Click on the file with the .DMG file extension (example: SP7600 1.6bE.dmg) to create the printer driver installation package.
- 3. The printer driver installation package installer has a .pkg extension (example: SPro7600_16b.**pkg**) double click on the file to start the printer driver installation.




Prior to starting the installation it is recommended you copy the installation package (example: SPro7600_16b.pkg)


to your hard drive. This will save you time should you wish to reinstall the driver in the future.



- 4. The installer requires your Macintosh password for Authentication. Enter your Password and click OK.
- 5. The Installer Introduction screen will be displayed, click CONTINUE.





6. Read the License Agreement and click CONTINUE. You are asked to Agree or Disagree to the License Agreement click AGREE to continue the installation.



7. Select the Destination Disk (your OS X volume) to install the driver on by clicking on its icon, then click CONTINUE.

Installation Type is the next step "EASY INSTALL" is the default to perform the basic driver installation, to continue click INSTALL.





- 8. Next you see a notification screen to Restart your computer after the installation is completed, to continue click CONTINUE INSTALLATION. The Printer Driver will now be installed, a progress window is displayed during the installation.
- 9. The Printer Driver will now be installed, a progress window is displayed during the installation.
- 10. When the Printer Driver installation has completed the following window is displayed, click RESTART to Finish the installation.



ADDING THE PRINTER TO PRINT CENTER


- 1. After the printer driver is installed you first need to register it with Print Center.
- 2. The Print Center Utility is located on your hard drive at the following location: /Applications/Utilities/Print Center.




Copy the Print Center to the Short Cut Task Bar for ease of access.




You have Two ways to Add a printer. You can use the Add button or you can select Add Printer from the Printers drop down menu, click Add.




4. On the Add printer window you first need to select the Epson Interface Connection the printer is attached with:




- 5. After you choose the Epson Interface Connection, the Print Center automatically searches the connection for printers. When the search completes:
 - 5.1 Select your printer from the list by clicking on it.
 - 5.2 Next select your Page Setup. Roll Paper is the default. If your work flow will include several of the choices they can be added individually, or to save time you can add all the choices by selecting All. The choices you make are print queues for the specific job types and will be listed in the Print Center.
 - 5.3 When you have completed making your Paper Setup choices click Add.




6. The printer and queues will be added to the Print Center Printer List:




7. To add or remove information displayed about the printer go to the View Menu and select Columns the choose the information you would like to display:




8. To make the printer the Default printer highlight the printer then go to the Printers Menu and select Make Default or click the Make Default button.



9. The Default printer will be highlighted in the Printer List:




10. To view the Job Status of a printer double click on it in the Printer List to display its information and status:




EPSON PRINTER UTILITY

- 1. You can access the Epson Printer Utility from the Print Center by:
 - 1.1 First selecting your printer from the Print Center Printer List.
 - 1.2 Next click Configure.
 - 1.3 Then from the new Printer List window select your printer and click OK.




1.4 From the Epson Printer Utility you can Check the Status of Ink-Paper-and the printer itself, perform print head Nozzle Checks, Clean the print head, or perform Print Head Alignments.




DRIVER REMOVAL

Before installing a New Driver you must first properly remove the existing Driver and all of its components.

1. Open the Epson Driver from any application and select print. Remove all user created "Presets" that were created for the printer you are removing. From the Presets drop down menu select the Preset (example: MYPRESET) then select Delete..




2. Next open the **Print Center** and remove all the printers queue entries for the printer you wish to un-install. Highlight the Queues and press the **Delete** button.




3. In the next steps you will be dragging Files or Folders to the Trash. OS X requires you to have proper "Ownership & Permissions" to the Epson folder on your OS X hard drive. Highlight the Epson folder then GoTo File, Get Info and select "Ownership & Permissions". Click on the Pad Lock to unlock it, then from the Owner dropdown menu choose the User name that was used to install OS X and/or the Printer Driver, in addition a password may be required if assigned for the user.



- 4. You have **TWO** choices for removing files from the Epson Folder. The two choices are outlined below:
 - 4.1 Removing **ONLY** the Stylus Pro 7600 or 9600 Plug-in and Preference from the Epson folder (**Preferred**).
 - 4.1.1 Drag the Stylus Pro 7600/9600 plug-in to the TRASH.



4.1.2 Drag the printers Preferences to the TRASH.




4.2 The second option is to drag the entire Epson folder to the Trash.



Dragging the entire Epson folder to the Trash Deletes ALL Epson Printers.

5. From the Receipts folder Drag the Printers Package information to the TRASH.



EPSON Product Support Bulletin

Date: 09/25/2002 Originator: MS
PSB #: PSB.2002.09.004 Authorization:

Reference: N/A Total Pages:

Product(s): EPSON Stylus Pro 9000, 9500, 9600, 7000, 7500, 7600, 10000, 10600, 5000,

5500 and Stylus Color 3000 Printers

Subject: PostScript Printing Support for Mac OS X Native Mode

This bulletin provides instructions for installing and configuring a Mac OS X Client with your existing EPSON hardware or software RIP. If your EPSON Professional Wide Format printer was bundled with one of the RIP packages listed below, or if you had purchased the RIP as an option, then you can configure a Mac OS X Client with OS Version 10.2 and above for PostScript printing by simply installing the appropriate RIP PPD.


- EFI RS 5000 LX Series Stylus Pro 5000 printer
- EFI RS 5100 X2 Series Stylus Pro 9000, 7000, 9500 and 7500 printers
- Fiery Spark Designer Stylus Pro 5500 printer
- Fiery Spark Professional 1.0 Stylus Pro 5500 and Stylus Pro 10000ARC/DYE printers
- Fiery Spark Professional 2.0 Stylus Pro 9600UCM/7600UCM printers
- EPSON StylusRIP Stylus Color 3000 and Stylus Pro 5000 printers

Installation Instructions:


Setup your existing RIP Server as per the instructions provided in the User's Guide that came with your RIP. To setup a Mac OS X Version 10.2 Client follow the instructions below. There are two ways you can add a PPD and configure your printer in OS X, **AppleTalk** or **IP Printing**.


AppleTalk Installation:

 Open the *Print Center*, which can be found on your hard disk driver under Applications - Utilities





2. Click on the *Add* button. Then select *AppleTalk* from the top sub-menu and your **AppleTalk** zone if applicable.







3. The **Print Center** should scan the network and find all your devices. Select your printer from the list and click on the **Printer Model** sub-menu. Select **Other** to continue.





4. Navigate to the location of your PPD file. After selecting the PPD file it should reflect the name of the printer under the **Printer Model** section. Click on the **Add** button.







Repeat the process to add your additional queues. Your Mac OS X Client should now be ready to print.

IP Printing Installation:

Open the *Print Center*, which can be found on your HDD under **Applications** - Utilities





2. Click on the *Add* button and select **IP Printing** from the sub-menu.






 Enter the IP Address of the Postscript Server under *Printer's Address*. Uncheck the Use default queue on server and type in the queue you wish to add. Click on the Printer Model sub-menu and select *Other*.






4. Navigate to the location of your PPD file. After selecting the PPD file it should reflect the name of the printer under the **Printer Model** section. Click on the **Add** button.






5. The Print Center should now show the Queue that you typed along with the IP address.



6. Repeat the process to add your additional queues. Your Mac OS X Client should now be ready to print.

Note: The StylusRIP does not have a separate folder on the CD to select the printer's PPD. In order to select the PPD it must be copied from another client's **Printer Description folder** as shown below (HDD - System folder - Extensions folder - Printer Description folder).



EPSON PRODUCT SUPPORT BULLETIN

Date: 05/02/2002 PSB No.: 2002.05.001 Reference: N/A Originator: RR Authorization:

Affected Product(s): EPSON Stylus Photo 2000P, Stylus Pro 7500 and Stylus Pro 9500

Subject: Updated drivers to address Metamerism

This bulletin provides information on which updated drivers to use for the EPSON Stylus Photo 2000P, Stylus Pro 7500 and Stylus Pro 9500 which address the issue of Metamerism.

Please Note: Use of this driver is optional. If you are producing prints that will be displayed under indoor lighting conditions at 6500°K this version of the driver is not recommended. If you are currently using a customized ICC color workflow it is very likely the profiles will need to be recreated for use with this new driver. This driver is also not recommended where prints will be viewed under a controlled light source and in applications of Fine Art, Photographic, or Black and White printing where ultimate print quality at all viewing distances is the primary requirement. The current driver and this new driver cannot be installed at the same time. You must first remove the current driver before installing this updated driver.

Overview of Metamerism:

Metamerism is the phenomenon of color prints being perceived differently when viewed under different light sources. This phenomenon is present to varying degree in all forms of pigmented ink printing and it is not possible to totally eliminate it. Unlike the EPSON Stylus Pro 5500 and the EPSON Stylus Pro 10000, which have hardware features designed to reduce Metamerism, the earlier model EPSON Stylus Photo 2000P, Stylus Pro 7500 and Stylus Pro 9500 do not have this same capability. Therefore, Epson has specifically developed a driver to reduce Metamerism on these products. While this driver reduces the light source color shift issue noticeable from all viewing distances, closer inspection of 1 ft or less will possibly show a slightly lower level of image quality which can be described as a coarseness or graininess in neutral, mid-tone and shadow areas of the print.

Drivers available for each model and operating system:

EPSON Stylus Photo 2000P								
http://support.epson.com/hardwa	http://support.epson.com/hardware/printer/inkjet/pho2kp/index.html							
Operating System	Driver File Name							
Windows NT 4.0	Epson10324.exe							
Windows 95/98/Me	Epson10323.exe							
Windows 2000/XP	Epson10325.exe							
Macintosh 8.51-9.22	Epson10326.sea.hqx							

EPSON Stylus Pro 7500							
http://support.epson.com/hardware/printer/inkjet/pro75_/index.html							
Operating System	Driver File Name						
Windows NT 4.0	Epson10016.exe						
Windows 95/98/Me	Epson10015.exe						
Windows 2000	Epson10014.exe						
Macintosh 8.51-9.22	Epson10020.sea.hqx						

EPSON Stylus Pro 9500 http://support.epson.com/hardware/printer/inkjet/pro95_/index.html				
Operating System	Driver File Name			
Windows NT 4.0	Epson10019.exe			
Windows 95/98/Me	Epson10018.exe			
Windows 2000	Epson10017.exe			
Macintosh 8.51-9.22	Epson10021.sea.hqx			

Date:1/23/02Originator:RRPSB #:PSB.2002.01.001Authorization:Authorization:Reference:N/ATotal Pages:12

Product(s): EPSON Stylus Color 3000, Stylus Pro 5000, 5500, 7000 Series, 9000 Series and 10000 Series

Subject: Maximum Printable Area Limits for the EPSON Professional Graphic Printer line.

This bulletin was created to inform you of the maximum custom page sizes allowable for EPSON Professional Graphic products. The tables below show the maximum page sizes allowable for the EPSON Professional Graphics printer line (Desktop and Large Format). Although this document is meant as a guideline for the maximum page size allowable for each printer, it does not include printable area (margin) information. Please refer to your user guide for additional information regarding the printable area (margins) for your particular printer. There are 3 aspects that effect how long of a page your printer can output. Those 3 items are:

1. Operating System.

- 2. Driver Specification.
- 3. Software application(s) being used.

Maximum custom page size allowable per operating system (for Epson standard driver):

	Stylus Color 3000	Stylus Pro 5000	Stylus Pro 5500	Stylus Pro 7000	Stylus Pro 7500	Stylus Pro 9000	Stylus Pro 9500	Stylus Pro 10000 Series
Macintosh OS	44 in.	44 in.	44 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.
Win 9x/Me	44 in.	44 in.	44 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.	90.5 in.
Win NT 4.0/2000/XP	44 in.	44 in.	44 in.	590.5 in.	590.5 in.	90.5 in.	590.5 in.	590.5 in.

Print jobs being sent through the Epson standard print driver should be in the RGB format in order for color management to be utilized properly.

Maximum custom page size allowable for EPSON PostScript options (PPD):

	Stylus	Stylus Pro						
	Color	5000	5500	7000	7500	9000	9500	10000
	3000							Series
EPSON Stylus RIP	44 in.	44 in.	N/A	N/A	N/A	N/A	N/A	N/A
EPSON Fiery RIP	N/A	44 in.	N/A	See NOTE	See NOTE	See NOTE	See NOTE	N/A
Station				1	1	1	1	
EPSON Fiery Spark	N/A	N/A	44 in.	N/A	N/A	N/A	N/A	N/A
Designer (Mac)								
EPSON Fiery Spark	N/A	N/A	44 in.	N/A	N/A	N/A	N/A	See NOTE
Professional								1

Print jobs being sent through the Epson PostScript driver can be either RGB or CMYK format. Settings in the RIP will determine how color management is used.

Maximum page size allowable from software applications:

	Stylus Color 3000	Stylus Pro 5000	Stylus Pro 5500	Stylus Pro 7000	Stylus Pro 7500	Stylus Pro 9000	Stylus Pro 9500	Stylus Pro 10000 Series
Adobe Photoshop	See NOTE	See NOTE	See NOTE	See NOTE	See NOTE	See NOTE	See NOTE	
5.x/6.x	2	2	2	2	2	2	2	2
*Adobe Illustrator	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.	227 in.
8.x/9.x								
QuarkXPress 4.x	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.	48 in.
*CoreIDRAW 8.x/9.x	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.	1,800 in.

* - These applications allow for tiling of print pages, therefore allowing you to print beyond the printers maximum page length limit and print to the applications limits. The printer driver must be set for Roll Paper (Banner) mode so that page breaks at the printer's maximum page length do not occur (in essence gives you a 0 margin for the bottom of the page). The Stylus Pro 5000/5500 however will give a slight page break at the 44 inch limit as these printers do not support banner mode. Also, printing certain elements from these applications may not utilize color management correctly/properly and may produce output color that is not expected.

NOTE 1:

- a. Under Win 9x/Me, the PPD limit is 129 inches.
- b. Under Windows NT, 2000 and XP, the PPD limit is 1771.6 inches (SP7000/9000 Series) and 1800 inches (SP10000 Series).
- c. Under Mac OS 8.x/9.x, the PPD limit is 273.06 inches.

NOTE 2:

Adobe Photoshop has a pixel limitation of 30,000 pixels, which means a document created @ 300ppi can only reach a maximum page size of 100 inches (H and V). When sending jobs to the printer via the standard non-PostScript print driver, Photoshop looks at the input resolution of the printer driver and adjusts the page size accordingly. All Epson large format printers use 360dpi as the input resolution (this is the resolution data is rasterized at), therefore when printing from Photoshop, the maximum page length you will be able to output to any Epson large format printer using the standard print driver would be 83.33 inches (30,000 pixels / 360dpi). As for the Epson desktop products, they rasterize data at 720dpi, therefore the maximum page length obtainable with the standard print driver would be 41.67 inches (30,000 pixels / 360dpi).

Also, under Photoshop 5.x/6.x for the Macintosh and Photoshop 6.x for the PC, the job will end up clipped if it is over the 83.3 inch printer page limit. If you are using Photoshop 5.x for the PC, the print job will actually be truncated to fit within the printable area of the printer. Be advised that you may not get a page size error. It may be useful to enable the "print preview" function of your printer driver (if available) so that you do not waste unnecessary media.


The only options for printing beyond the limitations is to save the file and print via an application that does not have the 30,000 pixel limit (may lose color management functions) or print the file through a PostScript RIP (which will allow for longer pages).

The following examples are how to setup banner printing from Adobe Illustrator 8.01 and CorelDRAW 9 from the PC platform. The Macintosh versions of these applications should be very similar in function. Please refer to your software documentation for additional assistance.

Adobe Illustrator 8.01:


In this example, we are creating a banner, which is 227 inches (Illustrators max. page setup).

- 1. Launch Illustrator and open or place your file in the page layout.
- 2. Click on File, then Document Setup. The following screen appears.




- 3. Uncheck **Use Print Setup**, enable **Tile Full Pages** and create the page size (in our example we used 44x227 inches).
- 4. Click, **Print Setup**. This will bring up the print driver.

5. Click on the **Paper Tab**. The following appears.




6. Set the Paper Source to Roll Paper (Banner) and also enable Save Roll Paper.

7. When creating the custom page size, divide the banner size by a value that will make it less than the printer maximum custom page size (not necessary for OS/Drivers that support 590.5 inches). In this example we take (227/3 = 75.7), therefore the custom page size created would be 44x75.7 inches. The reason for this is to save media.



8. After setting the custom page size and other driver settings (media type, resolution, etc.), click **OK**. This will bring you back to the document setup. The page should now show the following.




9. At this point you can and resize the image to fit within the printable area and print.

CoreIDRAW 9:


In this example, we are creating a banner, which is 227 inches.

- 1. Launch CorelDRAW and open or place an image in your page layout.
- 2. Adjust the page size and image for the document as shown in the following image.




3. Click on File and Print Setup.

4. Click on the **Paper Tab**. The following appears.




5. Set the Paper Source to Roll Paper (Banner) and also enable Save Roll Paper.

6. When creating the custom page size, divide the banner size by a value that will make it less than the printer maximum custom page size (not necessary for OS/Drivers that support 590.5 inches, unless the document is beyond that size). In this example we take (227/3 = 75.7), therefore the custom page size created would be 44x75.7 inches. The reason for this is to save media.




7. After setting the custom page size and other driver settings (media type, resolution, etc.), click **OK**. This will bring you back to the document.

8. At this point, click File then Print. CorelDRAW will then run a pre-flight check and will show the following window.



9. Click on the Layout Tab and enable Print Tiled Pages and set any additional parameters as you see fit.



10. At this point you could check other tab settings (if necessary) and click **Print Preview** (recommended) if you want to see how the file will be printed or **Print** to output the file to your printer.

For all other applications, please refer to your software documentation for information on maximum custom page sizes for documents, banners or tiling prints.

 Date:
 12/10/2001
 Originator:
 RR

 PSB #:
 PSB.2001.12.003
 Authorization:
 J#

 Reference:
 TE01-206 Rev. A
 Total Pages:
 3

Product(s): EPSON Stylus Pro 7500 / 9500

Subject: EPSON Fiery RIP Station 5100 Series III Media/Profile Updates

This bulletin was created to inform you of the new Media Update/Profiles for the EPSON Fiery RIP Station 5100 Series III.

Description of Change:

The initial release of the EPSON Fiery RIP Station 5100 Series III was limited on the media list it supported. This update provides those additional medias and profiles for use with the RIP Station 5100 Series III. The following procedure outlines the installation and implementation of the updated Media and Profiles for the RIP Station 5100 Series III.

Patch Installation:

- 1) Using the Downloader utility from the EPSON Fiery Command Workstation (PC) or Fiery Spooler (Mac), locate and download the patch files (vl000.PS vl990.PS) to the Print Queue. Refer to the RIP Station 5100 Series III "Job Management Guide" for details on downloading files to the RIP Station.
- 2) Once the download is completed, the RIP Station LED will display IDLE. At this point reboot the server.
- 3) Next, the ICC profiles should be copied to the appropriate Color (PC) or ColorSync (Mac) folders on your system.

Media list and Patch used:

Media Used	Mode Used
Photo Glossy Paper, Photo Semigloss Paper	Patch
or Premium Luster Photo Paper	
Smooth Fine Art Paper or Texture Fine Art	Patch
Paper	
Canvas	Patch
Heavyweight Polyester Banner	Set Print Mode to "Watercolor Paper-Radiant
	White" and profile for this media.
Adhesive Vinyl and Tyvek Brillion	Set Print Mode to "Synthetic Paper and profile
	for this media.

Downloading the Output profiles:

- 1) Open "Profile Manager". Refer to the RIP Station 5100 Series III "Color Guide" for details on using ColorWise ProTools.
- 2) Click "Browse", and select Profile Folder [Color (PC) or ColorSync (Mac)]. If the view in Profile Manager is set for description, you will see several descriptions listed on the left hand side of the screen. Please see "[Media and Profile]" for information about media and description of the ICC profiles.
- 3) Click a profile and download to Output.
- 4) Select the ICC profile in Output, and click "Profile Setting".
- 5) Check "Appear in Driver as..." and define a value. Use the chart below to define the values for the ICC profiles. You can also select "Default" if that is the default profile/media you want to use.

Profile	Appear in Driver As
Photo Glossy Paper	1
Photo Semigloss Paper	2
Premium Luster Photo Paper	3
Smooth Fine Art Paper	4
Textured Fine Art Paper	5
Canvas	6
Synthetic Paper	7
Adhesive Vinyl	8
Tyvek Brillion	9
Heavyweight Polyester Banner Paper	10

- 6) Click "OK".
- 7) For other profiles, repeat steps 3-7.

Printing from the Adobe PS Driver:

When printing from the Adobe PS driver, select Print Options and set the following selections for the new media/profile selections.

- a) **Print mode**: Refer to Media and Print mode settings for this setting.
- b) **Output Profile**: Output 1-10. This is the value you set in the Output menu of the Profile Manager.

Media and Print mode settings:

Media:	Print Mode:	Patch Used (Y/N)
Photo Glossy Paper	Reserve2	Υ
Photo Semigloss Paper	Reserve2	Υ
Premium Luster Photo Paper	Reserve2	Ϋ́
Smooth Fine Art Paper	Reserve2	Y
Texture Fine Art Paper	Reserve2	Y
Canvas	Reserve2	Y
ReserveMedia1	Reserve1	Υ
Adhesive Vinyl	Synthetic Paper	N
Tyvek Brillion	Synthetic Paper	N
Heavyweight Polyester	Watercolor Paper (Radiant	N
Banner	White)	

Media and Profiles used:

Media:	File Name:	Description
Photo Glossy Paper	SP9500SP.ICC	FSRIP SP9500 Photo Glossy Paper.icc
Photo Semigloss Paper	SP9500SS.ICC	FSRIP SP9500 Photo Semigloss Paper.icc
Premium Luster Photo Paper	SP9500PL.ICC	FSRIP SP9500 Premium Luster Photo Paper.icc
Smooth Fine Art Paper	SP9500SF.ICC	FSRIP SP9500 Smooth Fine Art Paper.icc
Texture Fine Art Paper	SP9500TF.ICC	FSRIP SP9500 Texture Fine Art Paper.icc
Canvas	SP9500CP.ICC	FSRIP SP9500 Canvas.icc
ReserveMedia1	SP9500S2.ICC	FSRIP SP9500 Synthetic Paper2.icc
Adhesive Vinyl	SP9500AV.ICC	FSRIP SP9500 Adhesive Vinyl.icc
Tyvek Brillion	SP9500 TB.ICC	FSRIP SP9500 Tyvek Brillion.icc
Heavyweight Polyester Banner	SP9500 PB.ICC	FSRIP SP9500 Hweight Polyester Banner.icc

NOTE:

- 1) This patch changes color for Reserve1 and Reserve2. If you have custom profiles using Reserve1 and Reserve2, backup the data and reload after applying the Patch.
- 2) Calibration is not supported through Reserve1 and Reserve2.

Date: 11/21/2001

PSB No.: PSB.2001.11.002

Reference: N/A
Originator: RD/RR
Authorization:

Affected Product(s): Epson Stylus Pro 5000/5500/7000/7500/9000/9500/10000/10000CF

Subject: Windows XP Driver & Status Monitor 3 Installation Procedure

This bulletin describes Windows XP printer driver/Epson Status Monitor 3 installation procedures for the following Epson printer models.


Model	Status Monitor 3	USB	IEEE 1394	Ethernet	Parallel
				(optional)	
Stylus Pro 5000	N/A	N/A	Yes (optional)	Yes	Yes
Stylus Pro 5500	Not available	Yes	Yes (optional)	Yes	Yes
Stylus Pro 7000	Yes	Yes	Yes (optional)	Yes	Yes
Stylus Pro 7500	Yes	Yes	Yes (optional)	Yes	Yes
Stylus Pro 9000	N/A	N/A	Yes (optional)	Yes	Yes
Stylus Pro 9500	Yes	N/A	Yes (optional)	Yes	Yes
Stylus Pro 10000	Not available	Yes	Yes	Yes	Yes
Stylus Pro 10000CF	Not available	Yes	Yes	Yes	Yes

The appropriate Windows XP driver/Status Monitor 3 can be downloaded from Epson America's support website, at http://support.epson.com/filelibrary.html. During the download process, choose "Save this program to disk" option to save the files to your local hard disk drive. When you are ready to install your printer driver/ Status Monitor 3, **Power OFF** you printer and restart you computer. Run the self-extracting executable file from the saved location on your hard disk drive and follow the installation instruction on the screen for your specific connection type.

Note: The screen shots shown in this bulletin reflect the Stylus Pro 9500 printer, but the installation instruction are identical for all of the printer models listed above.


Instructions for USB and Parallel Connection


1. At the EPSON Printer Utility Setup screen highlight your printer then click OK. Next, you will see the progress bar followed by the Windows Logo verification screen. Click on *Continue Anyway* option to continue.





2. As instructed at following EPSON Printer Utility Setup screen Power ON your printer. Your printer will be detected automatically. Select Install the software automatically (Recommended) option then click NEXT to continue at the Found New Hardware Wizard screen.





3. Your will be prompted with Windows Logo verification screen again, Click on *Continue Anyway* option to proceed to the next step. After the driver files have been copied to you local hard disk drive, click on Finish to compete the driver installation.






4. To install Epson Status Monitor 3 follow the instructions under section heading **Installation Procedure for Epson Status Monitor 3**.

Instructions for IEEE 1394 Connection

1. At the EPSON Printer Utility Setup screen highlight your printer then click OK. Next, you will see the progress bar followed by the Windows Logo verification screen. Click on *Continue Anyway* option to continue.





 As instructed at the following EPSON Printer Utility Setup screen Power ON your printer. The IEEE 1394 card will be detected automatically. At the Found New Hardware Wizard screen click on Install from a list or specific location (Advanced) option then click on Next to start the installation of the IEEE 1394 device driver.






3. On the screen shown below, uncheck Search removable media, click on Browse and navigate to the location of the extracted driver files (usually under C:\Epson\) and point to the WIN2000 folder. Select the folder then click on Next to continue and finish the IEEE 1394 driver installation.






5. The following Found New Hardware Wizard screen for IEEE 1394 status will be displayed. Select Install the software automatically (Recommended) option selected and click on Next to continue. After the driver files have been copied to you local hard disk drive, click on Finish to complete the driver installation.






6. After the IEEE 1394 driver installation is completed on the following Found New Hardware Wizard screen select, Install the software automatically (Recommended) option then click on Next to start the printer driver installation. Next, you will see the progress bar followed by the Windows Logo verification screen. Click on *Continue Anyway* option to continue.






7. After the driver files have been copied to you local hard disk drive, click on Finish to compete the driver installation.



8. To install Epson Status Monitor 3 follow the instructions under section heading **Installation Procedure for Epson Status Monitor 3**.


Instructions for Ethernet Connection

1. At the EPSON Printer Utility Setup screen highlight your printer then click OK. Next, you will see the progress bar followed by the Windows Logo verification screen. Click on *Continue Anyway* option to continue.





 At this point DO NOT POWER On your printer and at the EPSON Printer Utility Setup screen click on Stop searching button to continue with the installation. Next, you will see the progress bar followed by the Windows Logo verification screen. Select Continue Anyway option.







3. On the next screen your will be notified that the printer has been set to LPT1, click on OK to finish the driver installation.




4. **Power ON** your printer next, then you will need to redirect the port to the Type B Ethernet card's IP address. Click on the Start button, then Control Panel followed by Printers and Other Hardware then go to Printers and Faxes. Right click on the printer icon and choose Properties from the pop-up menu.




5. At the printer properties screen, click on Ports and then on the Add Port... button. On the Printer Ports screen, highlight Standard TCP/IP Port and click on New Port.






6. At the Add Standard TCP/IP Printer Port Wizard, screen click on Next. Then on the next screen type the Type B Ethernet card's IP address. Check with your System Administrator for the correct IP address assigned to the Epson Type B Ethernet card on your network.







7. If Windows identifies the Epson card automatically, click Finish at the Completing the Add Standard TCP/IP Printer Port Wizard. If your card is not identifies as an Epson network card automatically, click on Custom and then Settings. On the next screen select LPR, type PASSTHRU as the Queue Name, check SNMP Status Enabled and click OK. Click Next on the Add Standard TCP/IP Printer Port Wizard screen to continue with the installation, and then click Finish on the next screen. Click Close at the Printer Ports screen.







8. On the next screen click on Apply and then on Close to finish the installation. Your printer driver installation has been completed and the printer is ready to print.



9. To install Epson Status Monitor 3 follow the instructions under section heading <u>Installation Procedure for Epson Status Monitor 3</u>.

Installation procedure for Epson Status Monitor 3

1. At the EPSON Status Monitor 3 setup screen highlight your printer then click OK. Next, you will see the progress bar followed by a window indicating that EPSON Status Monitor 3 is complete.





Date: 09/06/2001

PSB No.: PSB.2001.09.002

Reference: N/A Originator: RR

Authorization:

Affected Product(s): Stylus Pro 7000 Series, 9000 Series and 10000 Series Large Format Printers

Subject: Printer Connectivity Issue due to Incorrect Model Name Selection - Printer Reports Off-Line

Issue Description:

- 1. **MAC Connection:** When connecting a Stylus Pro 7000 Series, 9000 Series or 10000 Series to an Apple Macintosh via USB, Ethernet or FireWire, the Macintosh's System Profiler sees the connection, but when going into the Chooser the connection does not show up when the appropriate printer driver is selected.
- 2. PC Connection: When connecting a Stylus Pro 7000 Series, 9000 Series or 10000 Series to a Windows PC via USB, Ethernet or FireWire and while attempting to print, an error message ("Printer Off-Line" or "Communication Error" on PC side) or ("Command Error" or "0002000B" on the LCD display of the printer) occurs.

Solution:

After verifying that all connections and port settings are good (on System and Printer) and that the printer is on-line, check that the model name of the printer is set correctly. To do this, follow these steps:

- 1. Shut printer off. Open the front cover.
- 2. While holding down the [SelecType] + [Paper Feed +] buttons, power the unit on.
- 3. The LCD display will then show the printer model name (it will show US and International model names). The following are the names that will show for each model type. The model name should match the driver selection.

SP7000 Series Names:	SP9000 Series Names:	SP10000 Series Names:
Stylus Pro 7000 (US name)	Stylus Pro 9000 (US name)	Stylus Pro 10000 (US name)
Stylus Pro 7500 (US name)	Stylus Pro 9500 (US name)	Stylus Pro 10000CF (US name)
PM-7000 (International name)	PM-9000 (International name)	PM-10000 (International name)
MC-7000 (International name)	MC-9000 (International name)	MC-10000 (International name)

- 4. If the incorrect model name selection appears, shut the unit off and repeat step 3 until the correct model name shows.
- 5. Once the proper name shows up, power the unit off, wait 15 seconds, close the front cover and power the unit back on.
- Once the printer is in a ready state, make the appropriate driver selection on your computer system. At this point the printer connection should work.

Date: 7/26/2001

PSB No.: PSB.2001.08.003 Reference: TE01-045 Rev. A Originator: JD, RR, TC & MS

Authorization: /#

Affected Product(s): EPSON Pro Graphic Printers Subject: Compatibility Chart for Macintosh OS X Classic

This bulletin provides information on compatibility for EPSON's Pro Graphic printers running in Macintosh OS X Classic mode. Mac OS X provides the Classic environment mode for Mac OS 9 compatible applications and device drivers. Classic mode will require Mac OS 9.1 system software. To setup Classic mode follow the steps below:

- 1. First install or upgrade your Macintosh system to OS 9.1 before installing OS X (for details refer to Apple's OS X documentation).
- 2. To start in Classic mode, click the *Classic* icon in System Preferences. To find *System Preferences* go to the *Apple Menu* or click on the icon in the *Dock* bar on the desktop. Classic mode can also be set up to start automatically during the log in process. (Refer to your Apple documentation for installation and operation of Macintosh OS X Classic and 9.1).
- 3. To run a Classic application, just double–click on it or a document created with the application.

A) The following Epson models are supported in OS X Classic mode when using the connector type(s) described in the chart below.

Model	Driver Version	Connector Type
Stylus Color 3000	5.69E	Ethernet I/F
Stylus Pro 5000	5.69E	Ethernet I/F
Stylus Pro 5500	6.61E	USB/Ethernet I/F
Stylus Pro 7000	6.63E	USB/Ethernet I/F
Stylus Pro 7500	6.73E	USB/Ethernet I/F
Stylus Pro 9000	6.30E	Ethernet I/F
Stylus Pro 9500	6.73E	Ethernet I/F
Stylus Pro 10000/10000CF	6.63E	USB/Ethernet I/F

Note:

- 1. MAC OS X Classic mode supports USB-native and network-capable devices. Classic mode does not support MAC Serial, SCSI or FireWire connected devices.
- 2. Printers using a Fiery Rip Station for PostScript printing are not yet supported at this time.
- 3. Printers using Stylus Rip with Adobe PostScript drivers are not yet supported at this time.
- B) The following models are not supported in OS X Classic when using the connector type(s) described in the chart below.

Model	Connector Type
Stylus Color 3000	Serial/Parallel-to-USB adapter/FireWire (IEEE 1394)
Stylus Pro 5000	Serial/ Parallel-to-USB adapter/FireWire (IEEE 1394)
Stylus Pro 5500	FireWire (IEEE 1394)
Stylus Pro 7000	FireWire (IEEE-1394)
Stylus Pro 7500	FireWire (IEEE-1394)
Stylus Pro 9000	Serial/Parallel-to-USB adapter/FireWire (IEEE 1394)
Stylus Pro 9500	Serial/Parallel-to-USB adapter/FireWire (IEEE 1394)
Stylus Pro 10000/10000CF	FireWire (IEEE-1394)

Date: 6/26/01

PSB No.: PSB 2001.06.004

Reference: N/A
Originator: TC/RR
Authorization:

Affected Product(s): SC3000, SP5000, SP5500, SP7000, SP7500, SP9000, SP9500, SP10000 DYE, and SP10000

ARC

Subject: Current Driver Location for C823722 EPSON IEEE 1394 (FireWire) Type B Interface Card for

Windows 2000/Me/Macintosh Operating Systems

This bulletin provides information on where to find the most current driver for the EPSON C823722 - IEEE 1394 (FireWire) Type B Interface Card for the following EPSON Professional Graphics Inkjet Printers with appropriate Operating Systems: SC3000, SP5000, SP500

- 1. Windows Requirements: The EPSON C823722 IEEE 1394 (FireWire) Type B Interface Card only supports factory preinstalled full versions of Windows 2000 and Windows Me Operating Systems
- 2. Macintosh Requirements: The IEEE 1394 (FireWire) drivers for the Apple Macintosh Operating System (OS 8.6 with FireWire Update 2.1 or later required) are all ready built into the EPSON printer driver, and require no other driver files.

The driver CD that comes in the box with the EPSON C823722 - IEEE 1394 (FireWire) Type B Interface Card may contain older drivers than what is available on the CD that came with your EPSON Printer or from EPSON Internet Support Web Site. Prior to installing your printer, please refer to the **IEEE 1394 Reference Table** below for the location of the latest drivers for your specific EPSON printer and operating system. If the driver your need is listed as "Update on the Web" the most current driver can be found on the EPSON Internet Support Web Site at: http://support.epson.com/filelibrary.html

IEEE 1394 Reference Table:

Printer Models:	Windows 2000	Windows Me
EPSON Stylus COLOR 3000	Update on the Web	Update on the Web
EPSON Stylus PRO 5000	Update on the Web	Update on the Web
EPSON Stylus PRO 5500	Driver that came with printer	Driver that came with printer
EPSON Stylus PRO 7000	Update on the Web	Driver on CD-ROM that came with C823722 card
EPSON Stylus PRO 7500	Update on the Web	Driver on CD-ROM that came with C823722 card
EPSON Stylus PRO 9000	Update on the Web	Driver on CD-ROM that came with C823722 card
EPSON Stylus PRO 9500	Update on the Web	Driver on CD-ROM that came with C823722 card
EPSON Stylus PRO 10000	Driver that came with printer	Driver that came with printer
EPSON Stylus PRO 10000CF	Driver that came with printer	Driver that came with printer